


Find yours

⏪ How to connect to WiFi on a Chromebook


Step 1

Click on the Quick Settings Panel at the bottom right of your screen.




Click on “no-network.”

Find yours



Step 3

Select your Wifi Network.



Pick one and enter the password if it calls for one.

Find yours

Join Wi-Fi network

SID

Network

Security

PSK (WPA or RSN)

Password

Allow other users of this device to use this network


[Cancel](#) [Connect](#)

Was this helpful?

[Yes](#)
[No](#)

Related Tips

More tutorials to show you how to make the most of your Chromebook.



DO MORE

How to
Connect
to
Bluetooth



DO MORE

How to
Set Up
Offline
Mode

What are Chromebooks

More Questions?

Search Support

Shop

Laptop

Convertible

Tablet

Special perks

Dev & partners

Chromium OS

Chrome
Experiments

Google Code


Education/Business

Chromebooks for
education

Chromebooks for
enterprise

The latest

 Blog

 Youtube
channel